## **GU10 Surface Downlight**

Installation instructions for JC84320

## Warnings & Cautions

- To avoid electric shock, serious injury or property damage, isolate power before installing, removing or installing the product
- It is recommended that luminaires are installed by a qualified electrician and the installation complies with the local current wiring regulations
- It may be necessary to upgrade your MCBs to allow for increased inrush current
- These products are designed for connection to a 220-240V~ 50/60Hz



- This product is for indoor use only.
- The light source in this luminaire is replaceable: when the light source reaches its end of life the light source can be replaced by the end user
- Any broken or damaged parts should be replaced as soon as possible. JCC will not accept responsibility for claims arising from sub-standard installations; which will void the warranty
- For ceiling mounting only, not suitable for wall mounting
- Do not use halogen lamps in this product

## INSTALLATION ENGLISH Specification: GU10 cap 7W LED max (lamp not included) Available finishes: Black(BLK) or White(WH) Fig 1 220-240V~ 50/60Hz Class I Fig 3 Fig 2. Mains Input Live = Brown $( \mathbb{D} )$ Live = Brown Yellow/green Yellow/green $( \mathbb{D} )$ $\square$ Neutral = Blue Neutral = Blue







Fig 4

Fig 5



## Installation procedure

1. Unscrew cylinder diffuser from main body (fig 1). Determine mounting location using the main body as a template, drill holes and insert plastic plugs.

- 2. Connect the mains input (fig. 2) and secure main body to ceiling (fig 3).
- **3.** Place lamp in lampholder (fig 4).

**4.** Screw cyclinder diffuser back onto main body (fig 5). Be careful not to overtighten.

5. Reconnect mains power supply and test for operation.

